

MAGIC TANK

OPERATING INSTRUCTIONS

Protective Equipment

Removing the basket - Wear heat resistant gloves when removing the basket (temperature is about 80 degrees Celsius)

Sensitive Skin - Rubber washing up gloves or similar should be used when sensitivity to detergent solution occurs. The cleaning solution is not toxic or corrosive and will not harm skin or clothes. In cases of skin sensitivity rubber gloves should be worn. The operating temperature of the Magic Tank is 80 degrees Celsius inside the tank only. **DO NOT** put hands in the solution as it is hot.

Operating Instructions

Loading the Magic Tank

1. To remove the basket use **heat resistant gloves**.
2. Lift the basket to a comfortable working height and lock into position.
3. Load the basket. Always stand trays, tins, wires, etc on their side.
4. For very dirty items soak overnight or 12 hours, rinse thoroughly with cold water and re-soak. Repeat as necessary.

Unloading the Magic Tank

1. Open the lid.
2. To remove basket use **heat resistant gloves**.
3. Lift the basket to a comfortable working height and lock in position.
4. Remove clean items and rinse thoroughly with cold water. Gloves should be worn..
5. Reload Magic Tank if additional items need to be washed or soaked.
6. Lower the basket.
7. Close the lid.

Maintenance

Daily

1. Ensure the tank is turned on and the cleaning solution is hot.(steam visible when the lid is opened).
2. Check water level and top up with clear water as required. The water level should be level with the indicator mark inside the tank. NEVER drain the solution from Magic Tank.
3. Call Magic Tank representative if repairs are required.

Weekly

1. Wipe the Magic Tank (outside only) with a wet/damp cloth.
2. Skim any excess fats / oils on the surface of the water and dispose of in the waste bin.

Monthly

1. Magic Tank representative will perform the monthly chemical change and service.

Emergency Procedure

1. Turn off the Magic Tank at the switch on the side of the unit.
2. Unplug the Magic Tank from the wall socket.
3. Call your Magic Tank representative.
4. Consult the MSDS if required .

Sales & Service 0421 669 915